

Product Installation Guide

Door Hinge & Locking Point Adjustments

Door Hinge Adjustments



1. Gasket compression adjustment ± 1 mm and additionally $\pm .75$ mm
2. Lateral adjustment ± 5 mm
3. Height adjustment $+5/-1$ mm

Locking Point Adjustments (Standard Security & WK1)

Locking Cam E	Locking Cam P
<p>Original position 0°</p>	<p>Original position 0°</p>
<p>90° 90° ± 0.8 +</p>	<p>90° 90° ± 0.8 +</p>
<p>4 mm Allen key</p>	<p>4 mm Allen key</p>

WK2 Security

Locking Cam V (included with accessories)	Adjustment range in °	Gasket-compression adjustment in mm	Height adjustment in mm
<p>0 = Original position</p> <p>Original position 0°</p>	<p>Original position 0°</p>	-	-
<p>90° 90°</p>	± 0.8 +	± 0.2 +	
<p>180° 180°</p> <p>- 0.8 max. adjustment</p>	-	± 0.4 +	
<p>270° 270°</p> <p>+ 0.8 max. adjustment</p>	± 0.8 +	± 0.6 +	
<p>360° 360°</p>	-	± 0.8 +	