
# **INSTALLATION INSTRUCTIONS**

# 2 PANEL SLIDING GLASS DOOR NARROWLINE | GRANDLINE





v.5 010825 Page **1** of **2**0

# Contents

1)	Receiving and Inspection4
2)	Prepare Rough Opening (RO)
S	ILL PAN & FLASHING NOTES6
S	HIMMING GUIDELINES
S	CREW FASTENER GUIDELINES
3)	Installing the Door
4)	Install Fixed Panel
5)	Install Dust Plugs
6)	Install the Fixed Panel Interlock
7)	Install the Active panel
8)	Fasten Top Dust Plug
9)	Adjust Panel Rollers
10)	Install Head Stop Bumper21
11)	Install the Handles and Check/Adjust Locks22
12)	Installing the Insect Screen
13)	Final Check for Square and Door Operation24
14)	Complete Flashing
15)	Finishing IIn

# FRAME KIT COMPONENTS

### 2-Panel Door

Qty	Part #	Components	ОХО	ООХ	ОХХО
1	SV5202/5201	Door Frame with Sloped Sill			
1		Sliding (Active) Panel			
1		Fixed Panel			
1	SV5205	Interlock for Fixed Panel			
1	SV???	Fixed Panel Riser			
1	SV5222	Fixed Panel Block			
1	GWC5234	Door Bumper Stop	1	1	2
1	GWC5232	Bottom Dust Plug – Sliding Panel			
1	GWC5231	Top Dust Plug – Sliding Panel			
2	GWC082218	Fixed Panel Anchors / L-Brackets	4	4	<mark>4</mark>
2	FGL1235.003	Weep Hole Covers	4	<mark>6</mark>	8
2		Hole Plugs - Operable Panel Rollers	2	2	<mark>4</mark>
<mark>4</mark>	#8 x ¾" PH	Fixed Panel Interlock Screws	4	4	8
<mark>2</mark>	#8 x 1-1/2" PH	Fixed Panel Riser Screws			
3	#10 x 1" CSK	Fixed Panel Anchor Head/Sill Screws			
2	#8 x 3/4" CSK	Fixed Panel Anchor Panel Screws			
2	#8 x 5/8" Self Tap	Door Bumper Stop Screws			
4	<b>??</b>	Top / Header Dust Plug Screws			
2	??	Bottom Dust Plug Screws			
2	??	Fixed Panel Block Screws			
20	#10 x 3"	Installation Screws			
20	½" Hole Plugs	Installation Plugs (Black or White)			
1	40.94 / 40.70	Handle Set with Screws & Gaskets			

3-PAN	3-PANEL AND 4-PANEL KIT COMPONENTS:				
0	SV5206	Astragal	0	1	1
0	½" Hole Plugs	Astragal Hole Plugs (Black or White)	0	4	4

FIELD	FIELD-ASSEMBLED FRAME KNOCK-DOWN (KD) KIT COMPONENTS:				
1	SV5202	Head frame			
2	SV5202	Side Jamb frames			
1	SV5201	Sloped Sill			
2	GWC5230	Frame Corner Key – Head/Jamb			
32	#10 x 1-1/2" PH	Head/Jamb Screws			
8	#10 x 1" PH	Sill/Jamb Screws			
2		Xtrabond 9500 Polyurethane Sealant			
		(White, Dark Bronze, Almond, Silver)			

v.5 010825 Page **3** of **26** 

# Sliding Glass Door Installation

Understanding the design and existing conditions of the building envelope under consideration is important for proper installation of fenestration products. Building materials, methods, and designs vary between projects. It is the responsibility of the installer to determine the proper installation method. Please consult your architect or a construction professional if necessary. No less than two (2) people are required for installation.

### **QUICK-GLANCE PLANNING:**

- Rough Opening framing must be at least:
  - o 3/4" wider than the door frame width and
  - o 1/2" taller than the door frame height.

This provides sufficient space to accommodate any flashing buildup without encroaching on the shim space, allowing the door to "float" and remain unaffected by building movement.

Dimension	Formula
Rough Opening Width	Door Frame Width + 3/4"
Rough Opening Height	Door Frame Height + 1/2"

 Installation screws for wood frame structure are included in your installation package. If your structure is not wood, consult "Appropriate Alternative Screws" Tables in Section 8

## 1) RECEIVING AND INSPECTION

- **A.** Inspect each door thoroughly upon delivery. Ensure each door is the proper type, operability, and dimensions. Check for any shipping damage and report it immediately to Alpen.
- **B.** If installation will not take place immediately after the door is delivered, proper storage techniques must be followed. Below are the recommended storage methods and guidelines.
  - Transport doors in an upright position with manufacturer's packaging in place. Store doors in an upright position (as close to 90° as possible), on the sill, on a flat & level surface, and away from any moisture. If door panels are not inside the frame, they must be stored in a vertical position at 90° to the ground.
  - o Do not lay, transport, or carry the door while in a flat (table-top) position.
  - Handle units with shipping handles or glass suction cups as much as possible.
  - Do not stack doors against each other. Do not stack any other materials or products against the door.

# REMEMBER TO USE APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT AND PROVIDE ADEQUATE MANPOWER AND EQUIPMENT FOR LIFTING HEAVY DOORS

### REMEMBER:

Always check door operation before applying final sealants and trim!! Incorrect operation is a sign that something is wrong with the installation and door may need to be re-set.


v.5 010825 Page **4** of **26** 


# 2) PREPARE ROUGH OPENING (RO)

TOOLS REQUIRED: 6 FOOT LEVEL • FRAMING SQUARE

#### A. CHECK OPENING AND DIMENSIONS

- 1) Ensure the opening is clean and free of debris.
- 2) Check SQUARE, LEVEL, PLUMB & FLAT (Fig. 20)
  - SQUARE: Measure the distance between opposite corners. If the measurements are
    the same, the opening is square. Use a framing square to check each corner of the
    RO.
  - LEVEL: Use a 6-foot level to determine if the sill and header are level, and the jambs are plumb.
  - o **PLUMB:** Use a **6-foot level** to check that all members of the wall are straight and parallel.
  - o **FLAT:** Lastly, check that the sub-floor is flat, straight, and level.
- 3) MEASURE Rough Opening. (Fig. 21)







Pro Move: Start with a Flat and Level Sill

**The number one cause** of poor door performance is an un-level sill. Sills with any **crown**, **bow**, or **slope** prevent the interlocks and weather stripping from engaging, leading to frustrating issues. If you start with a level sill, good results are all but assured. If the sill is not level, bad results will surely follow.

For best results, ensure the sill is perfectly flat and level before installation

v.5 010825 Page **5** of **26** 


### SILL PAN & FLASHING NOTES

This installation packet includes the recommended guidelines for applying flashing, which align with typical best practices. In all instances, follow the instructions provided by the architectural documents, building engineer and Weather Resistant Barrier system manufacturer. For complete guidelines and training on proper flashing application, refer to ASTM E2112-01 and AAMA Installation Masters.

Following these practices will help establish a secure seal between the door and rough opening (RO) while effectively channeling water to the exterior of the structure.

Alpen strongly recommends using sill pan flashing for door installations whenever feasible. The Sill pan flashing enhances water resistance and reinforces the building's enclosure integrity.

The sill pan flashing can be pre-formed or built in-place but must always be modifiable to custom-fit the specific sill condition, extending fully beneath the door to match the sill's shape. Always provide interior upstanding leg (back-dam) that is minimum 1-3/4" tall and use end caps that are at least as tall as the interior upstanding leg of the sill pan. Seal all joints between the sill pan and end caps (see Fig. 22). For more details on back dam heights, side jamb heights for flashing, redundant sealant lines, and flashing in a weatherboard fashion, please refer to the Installation Masters guidelines.



Source: AAMA Installation Masters Training Material

It is essential to insulate the cavity between the rough opening (RO) and the door frame, as well as seal the door to the interior of the building before the interior trim-out. This should be done in the manner best suited to the specific opening conditions.


v.5 010825 Page **6** of **26** 

### B. APPLY SILL FLASHING AND SILL PAN

- 1) Clean the opening: Ensure it is dry and free from dirt, oil and debris.
- 2) Install Sill pan flashing: Install 9" wide, flexible flashing on the sill, overlapping the sill plate, and up the jambs, 6" to 9" high. (See Table 2 on Pg.15 for flashing length formulas.)
- 3) Prepare a Sill Pan with Back-Dam:
  - Prepare pre-manufactured plastic pan or flexible flashing sill pan. Sill pan should have a 1-3/4" tall back-dam and end-dams and extend 2" across the face of the sheathing.
  - Place the sill pan on top of the sill pan flashing to make sure it fits tight between the jambs with the lip of the sill pan against the sill plate. Check that it is level.
  - o If the condition is not level, use leveling shims under the sill pan as opposed to under the door (Fig 1). Use flat shims of 1/8" or less set in bed(s) of sealant.

### 4) Install sill pan:


- Apply two 3/8" beads of sealant on top of the flashing, extending full width of sill. Place
  one bead on the interior side and one on the exterior side where the sill pan will make
  contact. Continue both beads up the jambs to seal the end-dams.
- Carefully place the sill pan into position, pressing it down onto the sealant beads and over any applied flexible flashing materials.
- Check that sill pan is level again.




v.5 010825 Page **7** of **26** 

### C. APPLY HEAD AND JAMB FLASHING

- 1) Starting at the top, work flexible flashing down each jamb. If using tapes, apply tapes starting at the inside and work toward the outside, pressing out any bubbles or voids.
- 2) Seal bottom of Jamb Flashing: Jamb Flashing overlaps the sill pan at the bottom, apply sealant as needed to ensure water-tight corner.





PRO TIP: Choose flexible flashing that is properly sized (See Table 2) to provide the following:


- Length should be long enough to cover the full height of the jambs and overlap the Sill Pan at the bottom.
- Flashing should extend minimum 6" into the opening so that end of flashing is at least ½" behind the inside edge of the door frame to ensure that the interior air seal is applied to both door frame and flashing.
- o Flashing should extend minimum 2" across face of sheathing.

Table 2			
Flashing Lengths and Cut Formulas			
<b>Sill Flashing</b> = RO <sup>W</sup> + (2 x Flashing Width)			
<b>Jamb Flashing</b> = $RO^H + (2 \times Flashing Width) - 1"$			
Head Flashing	= ROW + (2 x Flashing Width) + 2"		
Legend			
RO = Rough Opening RO <sup>H</sup> = Rough Opening Vertical Height RO <sup>W</sup> = Rough Opening Horizontal Width			
Source: AAMA Installation Masters Training Material			

v.5 010825 Page **8** of **26** 

### D. APPLY HEAD FLASHING

- 1) Flash across the Head of the opening
  - Wrap Flashing: Like at Jambs, head flashing should overlap sheathing minimum 2" and wrap into opening minimum 6".



### E. MEASURE THE RESULTING FLASHED OPENING:

- 2) The new door must be 1/2" to 3/4" smaller in width and 3/8" to 1/2" smaller in height than this measurement.
  - It is recommended to dry-fit the door into place at this time to check fit, plumb and level. If shims are necessary, use maximum 1/8" thick plastic horseshoe shims, set in bed of sealant.
  - Center the door in the opening and determine the shim size needed to keep it straight while anchoring. Use ¼" horseshoe shims or a WinBag™ inflatable shim for tighter spaces.





The  $WinBag^{TM}$  is an inflatable temporary air shim designed to help level and position doors and windows. Made from durable, flexible material with a manual pump, it allows precise adjustments by inflating to the desired thickness.

For door installation, it easily aligns frames for a secure, square fit, preventing long-term issues like sagging or misalignment.

Source: winbagusa.com

v.5 010825 Page **9** of **26** 

### **SHIMMING GUIDELINES**

Installation and adjustment of shims must abide by the following guidelines.

### There must be a shim at each fastening location.

- O Shims shall be rectangular or horseshoe style, made of high impact plastic, 1/8" minimum thick.
- Never use wood shims
- o Thicker shims may be required depending on the RO.
- If using tapered shims, always install them in complementary pairs with two shims oriented in opposite directions. This will ensure a flat level surface to support the door.



- O Shims must be a minimum of 1 ½" wide and long enough to provide continuous contact and uniform support across the entire depth of the door frame (5.5").
- When securing the door frame, ensure that fasteners are inserted at shim locations and penetrate through the shim into the RO.
- o Place lateral shims between side jambs and frame to square door.



### **SCREW FASTENER GUIDELINES**

If Alpen-supplied screws are missing or not appropriate for your installation substrate, refer to **Table 3** for appropriate alternate screws.

Table 3. APPROPRIATE ALTERNATE SCREW TYPES				
SPECIFICATION	DESCRIPTION			
MATERIAL:	High-quality, exterior-grade, corrosion-resistant stainless or coated steel; compatible with sealant materials (ASTM B766, B633, B456).			
SIZE:	#10 x length as needed to embed at least 1-1/2" into RO structure.			
Түре:	As suited to RO substrate (Wood Screw   Self-Tapping Sheet Metal Screw for Metal/Steel Structures   Concrete/Masonry screw for CMU)			
HEAD:	Flat, non-tapered head to fully cover 1/8" pilot hole.			
POINT TYPE:	Self-drilling or self-tapping.			

Screw Type	Application	Material
Self-Tapping Sheet Metal Screw	Thin metal frames or steel structures	Stainless or coated steel
Concrete/Masonry Screw (e.g., Tapcon)	Concrete or masonry substrates	Corrosion-resistant steel
Wood Screw	Wood framing or substrates	Stainless or coated steel
Structural Screw	High-load-bearing applications	Galvanized or stainless steel
Stainless Steel Deck Screw	Outdoor, corrosion-prone environments	Stainless steel

v.5 010825 Page **10** of **26** 


### 3) INSTALLING THE DOOR

ONLY BEGIN THIS STEP AFTER YOUR DOOR FRAME IS ASSEMBLED (IF KNOCK-DOWN KIT)

If your door is factory-assembled, you can start here. You may either set the door frame with the Fixed Panel already installed or remove the Fixed Panel first to reduce weight.

### A. Apply Sealant

- 1) Across sill near the front (exterior) edge of sill pan: Apply a discontinuous 3/8" bead of sealant. Leave 2" gaps near corners and about 48" apart.
- 2) Across sill ½" away from Back-Dam: Apply a second 3/8" bead of sealant. Leave 2" gaps near corners and about 48" apart, slightly staggered from the gaps in the first sealant bead.
- 3) Across the face of the Back-Dam: Apply a continuous 3/8" bead of sealant across the back-dam (the up-turned leg of the sill pan) and 6" up each jamb.





#### Sill Pan Terminology

End Dams: Side walls that prevent water from leaking beneath the sill pan from the sides.

**Back-Dam:** Stops wind- and pressure-driven moisture from damaging your floors.

Sloped Sill: Direct water outward and away from the opening.

Self-Sealing Material: These n


These materials form a watertight seal around fasteners, resisting cracking or leaking when punctured, to offer superior moisture protection.

Source: VersaPan™ by Endura Products

v.5 010825 Page **11** of **26** 

### B. Set and Secure the Door

- 1) Set the door frame near the rough opening (RO).
- 2) Locate the top two pre-drilled holes on the frame jambs (Fig. 5).
  - o Remove hole plugs and **save them**.
  - o These locations will be used as temporary anchor points.
- 3) Carefully lift the frame and set it onto the sill pan, keeping the pan sealant intact.
- 4) Insert shims the (top two jamb) temporary anchor points (Fig. 6)
  - Locate Shims behind (Fig. 7) or on either side of (Fig. 8) screw-hole location.
- 5) Use 1/8" Drill Bit to pre-drill through Back Wall of frame profile. (Fig. 6)
- 6) Install two (2) #10 x 3" screws (wood screws provided) in the pre-drilled holes to temporarily hold the door in place.



# STOP! CHECK THAT THE DOOR FRAME IS SQUARE, LEVEL, PLUMB AND CENTERED IN THE OPENING

ADD SHIMS AS NEEDED

Shim as needed (see "Shimming" section). If adding shims at the sill, take care not to disturb the sill sealant.

your installation substrate, refer to **Table 3** for appropriate alternate screws.


If Alpen-supplied screws are

missing or not appropriate for

v.5 010825 Page **12** of **26** 

### C. Secure Jambs and Head: Locate the remaining hole plugs, remove them, and repeat steps 4-6


- Fasten the door through each pre-drilled pilot hole using the appropriate fastener, checking plumb, level, and square regularly, and adjusting shims as needed.
- Don't be afraid to set the panels to check door operation early!
   (see next section) This allows for easier adjustments to the frame before final installation, avoiding the need to remove and reinstall the door later.
- D. Ensure there are six (6) fasteners per jamb and five (5) across the head.



### FOR RE-LOCATING SCREWS / DRILLING NEW SCREW-ANCHOR POINTS:

If there is a need to re-locate fastener holes (See Fig 10):

- 1) Use a Ø 1/2" diamond or fishtail bit and electric drill with drill-stop.
  - Not using the appropriate drill bit can result in tearing and fraying of the glass fibers in the door profile.
- Drill a Ø 1/2" hole through the FIRST WALL only.
   DO NOT DRILL DEEPER THAN 1/4"!
- 3) Pre-drill a Ø 1/8" hole through the **BACK WALL**
- 4) Add shims as above and fasten into the RO.
- Extra hole plugs are provided in your installation kit



v.5 010825 Page **13** of **26** 

### 4) INSTALL FIXED PANEL


**TOOLS NEEDED:** 

**GLASS CUP** 

2 PEOPLE

### A. INSTALL THE FIXED PANEL

- 1) Carefully lift the fixed panel up into the top portion of the installed door frame, and gently set it down onto the **Fixed Panel Riser**.
  - Ensure the cut out in the top of the panel seats around the track in the frame (Fig.11)
- 2) Slide the fixed panel over into the side jamb until it is fully seated into the door frame jamb.
  - Ensure it is seated fully into the side jamb. Bottom should be flush with the end of the Fixed Panel Riser.



FIXED PANEL INSTALLATION OCCURS FROM THE <u>EXTERIOR</u> SIDE.





**Pro Tip:** Use a wooden block and rubber or plastic mallet to tap the Fixed Panel into place to ensure it is fully seated into the jamb.


v.5 010825 Page **14** of **26** 

### B. ANCHOR THE FIXED PANEL (TOP)

1) Secure the Fixed Panel in place by installing the Fixed Panel L-Brackets

Ensure that both top and bottom L-brackets are centered and aligned with the groove in the door frame track.

- 2) Insert the top L-shaped metal anchor as shown. Align with pre-drilled Ø1/8" pilot holes.
- 3) Secure the metal anchor to the frame using one (1) #10 x 3/4" Phillips pan head screw (provided).
- 4) Secure the metal anchor to the fixed panel using one (1) #8 x 3/4" Pan Head screws (provided).





# IT IS IMPORTANT THAT THE PANEL ANCHORS ARE **EXACTLY CENTER** ON PANEL AND FRAME!


v.5 010825 Page **15** of **26** 

## C. ANCHOR THE FIXED PANEL (BOTTOM)


- 1) Insert the bottom metal anchor as shown.
- 2) Drill a 1/8" pilot hole in the sill portion of the frame and substrate.
- 3) Secure the metal anchor to the frame using one (1) 10 x 3/4" Phillips pan head screw (provided).
- 4) Secure the bottom anchor to the fixed panel using one (1) 8 x 3/4" Pan Head screws (provided).







fixed panel hidden for easier viewing of bottom bracket




v.5 010825 Page **16** of **26** 

# 5) Install Dust Plugs

### A. Bottom Dust Plug.

After securing the Fixed Panel in place and before the Fixed Panel Interlock is installed, locate the supplied Bottom Dust Plug.

- 1) Standing on the interior side of the door, identify the "Sill Riser-to-Fixed Panel Notch" where the Dust Plug will be installed.
- 1) Clean this area with alcohol and allow it to dry completely.
- 2) Install the Bottom Dust Plug by peeling off the adhesive cover and firmly pressing the Dust Plug into position flat on the door sill, between the Sill Track Riser and the Fixed Panel/Fixed Panel Riser at the open end (middle of door).



### B. Top Dust Plug.

After securing the Fixed Panel in place and before the Fixed Panel Interlock is installed, insert the Top Dust Plug

- 1) Again, while standing on the interior side of the door, locate the Top Dust Plug position: it's the large center channel at the head, situated between the two raised elements that serve as panel guides.
- 2) Slide the Dust Plug into the channel, positioning it to the side of the Fixed Panel.

DO NOT SCREW IN THE DUST PLUG YET!

v.5 010825 Page **17** of **26** 


# 6) Install the Fixed Panel Interlock

### A. Locate the two interlocks in the frame box.

- One is for the fixed panel This is the longer of the two interlocks.
- One for the active panel

### B. Snap in the Fixed Panel Interlock.

- 1) Standing on the **interior side** of the door, line up the fixed panel interlock with fixed panel so that it is flush with the top and bottom of the fixed panel.
  - o The groove with the pre-drilled screw holes will face *towards you* (Fig. 12)
- 2) Insert barb (Fig. 13) on exterior side of interlock into the groove on the fixed panel and tap into place.
  - Use block of wood or rubber mallet to avoid damage to the parts.
  - o Start at the top and carefully tap the interlock into the stile grooves.
  - Stop halfway down the interlock.
  - o Do the same starting at the bottom, working up towards the center of the interlock.
- **C.** Secure to the fixed panel from the interior side of the unit using (4) #8 x 3/4" Pan Head Fixed Panel Interlock Screws.



.5 010825 Page **18** of **26** 

TOOLS NEEDED: GLASS CUP

**IMPORTANT:** ENSURE THE ROLLER WHEELS ARE FULLY RETRACTED PRIOR TO INSTALLATION.

ROLLER WHEELS ARE SHIPPED IN THE RETRACTED POSITION.

IMPORTANT: THE ACTIVE PANEL MUST HAVE THE INTERLOCK COVER APPLIED BEFORE THE PANEL IS SET INTERLOCK SCREWS ARE NOT ACCESSIBLE AFTER THE PANEL IS SET IN PLACE.

(NEW DOORS / DOOR PANELS WILL BE SHIPPED WITH INTERLOCKS FACTORY-APPLIED)

#### A. Install the Active Panel

- 1) Using a Glass Cup, carefully lift the active panel up into the top portion of the installed door frame and gently set it down onto the roller track.
- 2) Ensure the cut out in the top of the panel seats around the track in the frame. (Fig. 14)
  - It is easiest to insert the active panel when it is in a central position (middle of the frame).
- 3) Slide the active panel over into the side jamb of the door frame.
  - Ensure the active and sliding panel interlocks properly meet when the active panel is in the closed position.

OCCURS FROM THE INTERIOR Fixed panel side Top portion jamb hidden for of frame easier viewing of panel. Side jamb Interio Exterior Active panel Cut out in top of Roller active wheels panel

v.5 010825 Page **19** of **26** 

ACTIVE PANEL INSTALLATION

### 8) FASTEN TOP DUST PLUG

- A. Slide the Dust Plug to the center of the interlock rails, positioning it 1-1/4" from the end of the Active Panel.
- **B.** Secure the Dust Plug with (2) black #8 self-tapping screws.

Note: This position interferes with the removal and reinstallation of the Active Panel. To remove the Active Panel, the Dust Plug must be repositioned to sit beside the Fixed Panel.



## 9) ADJUST PANEL ROLLERS

# THIS STEP REQUIRES AT LEAST TWO PEOPLE OR A 1-PERSON OPERATED VACUUM-LIFT WITH GLASS CUPS

TOOLS REQUIRED: GLASS CUPS, PHILLIPS-HEAD SCREWDRIVER

**A.** Lift the Panel: Use a Glass Cup to lift the panel: Ensure the weight is off the rollers before adjusting.

Warning: Adjusting the active panel with weight on the rollers may strip the adjustment screws.

Never use an impact driver or power drill.

#### B. Lower the Rollers:

While holding the panel up, lower the rollers (raising the panel) by adjusting the interior side screws with a hand screwdriver. Test door operation and continue adjusting the roller screws until the Active Panel is plumb and slides smoothly.

Warning: Failure to properly adjust the Active Door Panel after installation may damage the frame or sash and impact lock functionality.




\*NEVER ADJUST THE ROLLERS WITH AN IMPACT DRIVER OR POWER DRILL\*

v.5 010825 Page **20** of **26** 

# 10) INSTALL HEAD STOP BUMPER

- A. Insert the head stop bumper into the center channel of the head jamb, positioning it against the frame jamb where the Fixed Panel is located.
  - Seat stop bumper flush with head jamb and tight to the Jamb where the fixed panel is.
- B. Secure with one (1) #10 x 1" Pan Head self-tapping screw.




v.5 010825 Page **21** of **26** 

# 11) INSTALL THE HANDLES AND CHECK/ADJUST LOCKS

- A. Attach handle to the escutcheon plate using (2) machine screws (provided in box). Take care to pay attention to door handing:
  - o The curve of the handles should slope toward the center of the door.
- B. Install the handles according to the manufacturer's instructions
- C. Tighten securely to prevent loosening during operation.

CAUTION: DO NOT OVERTIGHTEN HANDLE SCREWS.

OVERTIGHTENED
HANDLE SCREWS WILL
COLLAPSE THE PANEL
CAVITY AND RESULT IN
COLLISION WITH THE
FRAME ACTIVE JAMB



- D. Test the lock functionality and adjust as necessary to ensure smooth operation and secure locking.
  - Adjust the keeper height as necessary by loosening the keeper screws and repositioning the keeper.
  - The lock strikers (throws/latches) can be adjusted by turning the slotted adjustment screw on the face of the mortise lock striker (throw/latch).
- E. Confirm that all components are properly aligned and make final adjustments to the locks if needed.


v.5 010825 Page **22** of **26** 

# 12) INSTALLING THE INSECT SCREEN

A. Mount the screen door on the outer track of the patio door. The top of the screen door will be inserted in the outer groove of the header.



The top of the roller screen will be inserted on the outer groove of the header.



Outer groove where the roller track gets inserted.



Mount the roller screen on the outer track of the sill.

v.5 010825 Page **23** of **26** 

### 13) FINAL CHECK FOR SQUARE AND DOOR OPERATION

\*Doors should NEVER be load bearing or contribute to the structural integrity of the building in any way after installation\*

### A. Final Check for Square:

- 1. Measure both diagonal distances on the interior of the door. These two lengths must be within 1/16" (2mm) of each other.
  - 2. The height of the frame at the center must be the same as the height at each end.
  - 3. The width of the frame at the center must be the same as the width on each end.

### **B. Final Door Operation Check:**

Final Adjustment of Rollers After Load Testing, after adjustments, simulate typical door use by opening and closing it multiple times to confirm smooth movement, proper locking, and alignment. Check that the rollers and track remain free of binding or sticking.

 Ensure there's no movement or flex in the frame under operational load, as this could indicate a need for further adjustment.

### C. Regular Maintenance Tip for Users:

Regularly clean out debris from tracks, weep holes, and seals. Dirt and debris buildup can hinder door operation and affect drainage over time.

 Ensure there's no movement or flex in the frame under operational load, as this could indicate a need for further adjustment.

#### D. Documentation and User Instructions:


### E. Provide the user with documentation on the final measurements for square, level, and plumb.

- Include maintenance instructions, specifically emphasizing regular track, roller, and weep hole cleaning to ensure optimal operation.
- Provide the user with a quick "Door 101" on basic operations locking, unlocking, rolling, and footlocks plus a hands-on demo for re-installing the sliding screen.
   (Because let's face it, someone will eventually plow through it like it's not even there!)

v.5 010825 Page **24** of **26** 

### 14) COMPLETE FLASHING

- A. Inspect all flashing and fasteners to ensure there is no damage to the water seal. Notes:
  - Only fully adhering flexible flashing shall be used and must meet AAMA 711
  - Sealant must meet ASTM C920
- B. (Exterior side) Install Drip Cap across door head (Fig. 18) and flash over it with head flashing (Fig. 19).
- C. Integrate all flashing with building's Weather Resistant Barrier (WRB) system (Fig.20) per WRB manufacturer's instructions.



- **D.** (Interior side) Install Air Seal: Insert backer rod between the door frame and the rough opening, using a rod approximately 35% larger than the gap width. Apply air-tight sealant over the backer rod, filling the cavity to seal the joint between the door and the rough opening. Form fillet joint that extends up onto face of door frame and across face of rough opening flashing to connect these elements.
  - Use Low-Expansion Foam Sparingly: Choose low-expansion foam specifically made for windows and doors. Too much foam or high-expansion types can distort the frame alignment.



### **PRO TIP:**

Remember that *interior* air-tight joints offer the best protection against wind-driven rain. Exterior joints are only secondary in moisture defense.

Image Source: Prosoco AirDam

v.5 010825 Page **25** of **26** 

### 15) **FINISHING UP**

- **A. Allow Sealant to Cure Fully:** Avoid disturbing the door system or subjecting it to movement or stress until the sealant has cured. This ensures a strong, durable seal.
- **B.** Inspect All Gaskets and Seals: Ensure that all door gaskets and weather seals are securely in place and undamaged, providing a continuous weather barrier.
- C. Check Weep Hole Covers: Ensure that weep hole covers are securely in place on the exterior side of the sill.
- **D. Double-Check Weep Holes / Drainage:** Before sealing or flashing, confirm that weep holes are clear of debris. Blocked weep holes can cause water to pool and damage the door system over time.
- **E. Re-Install Screw Hole Plugs in Frame:** Apply sealant to the screw hole plugs removed during frame installation, then insert them back into the clearance holes.
- F. Add color matching sealant or Mull Strips to the accessory groove to ensure it is fully covered.
- **G.** Install Roller Adjustment Hole Plugs: Locate roller adjustment hole plugs and insert them into the holes on the Active Panel(s).
- **H. Final Clean-Up:** Clean all surfaces around the door, removing any adhesive residue, fingerprints, or dust. This gives a polished look and ensures no residue interferes with sealant adhesion.



### **Pro Tips:**

Apply protective sheeting or masking over panels, glass, and frame during construction activities like painting, power washing, grinding and welding metals.



Protect the sill and sill roller track with cardboard if the door remains open during construction activities.

v.5 010825 Page **26** of **26**